



Boeing 787 Checklist

COCKPIT PREPARATION

Battery Switch.....ON
 C1 and C2 ELEC Pumps.....OFF
 Demand Pump Selectors.....OFF
 Wiper Selectors.....OFF
 Landing Gear Lever.....DOWN
 External Power.....ESTABLISHED

PRELIMINARY PRE-FLIGHT PROCEDURE

Lighting Panel.....SET
 IRS Selectors.....ON
 Status Display.....CHECK
 Parking Brake.....SET
 Cockpit Side Windows.....CHECK for CRAZING
 Emergency Equipment.....CHECK
 Flight Deck Door Access Sys.....CHECK
 Window Heat.....ON
 Walk-Around Inspection.....ACOMPLISHED

FMC Pre-Flight Procedure

Initial Data.....SET
 Navigation Data.....SET
 Performance Data.....OFF
 Right/Left Electrical Flight Bag.....SET

Pre-Flight Procedure Right Seat

Flight Control Surfaces Pnl.....SET
 Heading Reference Switch.....NORM
 Primary Flight Computers -
 Disconnect switch.....GUARD CLOSED
 Electrical Panel.....SET
 APU Selector.....START, then ON
 Left HUD Brightness Control.....IN
 Left Wiper selector.....OFF
 Towing Power Panel Lights.....OFF
 CCR Reset Switches.....GUARDS CLOSED
 Emergency Lights Switch.....GUARD CLOSED
 Service Interphone Switch.....OFF
 Passenger Oxygen ON Light.....VERIFY EXTINGUISHED
 Window Heat Panel.....SET
 Ram Air Turbine Unlocked Light.....VERIFY EXTINGUISHED
 Hydraulic Panel.....SET

Pre-Flight Procedure Right Seat (Cont.)

Seat Belt Sign Selector.....OFF
 Ground Test Selector.....OFF
 APU Fire Panel.....NORM
 Cargo Fire Panel.....SET
 Engine Panel.....SET
 Fuel Jettison Panel.....SET
 Fuel Panel.....SET
 Anti-Ice Panel.....SET
 Lighting Panel.....SET
 Broadband Comm's Switch.....ON
 ELT Switch.....GUARD CLOSED
 Humidification Switch.....ON
 Cargo Temperature Control Panel.....SET
 Air Conditioning Panel.....SET
 Pressurization Panel.....SET
 Right Wiper Selector.....OFF
 Right HUD Brightness Control.....IN
 Magnetic Standby Compass.....CHECK
 Mode Control Panel.....SET
 Display Select Panel.....SET
 EICAS Transfer Switches.....SELECT
 ENG Display Switch.....SELECT
 Secondary Engine Indications.....CHECK
 Engine Oil Quantity (min).....CHECK
 Electronic Checklist.....CHECK
 Airport Database.....CHECK
 EFIS Control Panel.....SET
 Integrated Standby Flight Display.....SET
 Landing Gear Panel.....SET
 Flight Instruments.....CHECK
 Air Data / Altitude Source Selector.....AUTO
 PFD/MFD Selector.....NORM
 Forward Panel Brightness.....MID POSITION
 Oxygen.....TEST and SET
 Speedbrake Lever.....DOWN
 Reverse Thrust Levers.....DOWN
 Forward Thrust Levers.....CLOSED
 Flap Lever.....SET
 Parking Brake.....SET
 Stabilizer Cutout Switches.....GUARDS CLOSED
 Fuel Control Switches.....CUTOFF



Boeing 787 Checklist

Pre-Flight Procedure Right Seat (Cont.)

Fuel Control Switch Fire
Warning Lights.....VERIFY EXTINGUISHED
Alternate Flaps Panel.....SET
Left Tuning & Control Panel.....SET
Observer's Audio Control Panel.....AS NEEDED
Flight Deck Door Access Selector.....AUTO
Engine Fire Panel.....SET
Glideslope Inhibit Switch.....Lights EXTINGUISHED
Transponder Mode Selector.....STBY
Aural Cancel Light.....EXTINGUISHED
Center Turning and Control Panel.....SET
Rudder Trim.....CENTERED
Flight Deck Printer.....SET
Right Tuning and Control Panel.....SET
First Officer's Audio Control Panel.....AS NEEDED
Floor Lights Switch.....AS NEEDED
Evacuation Command Switch.....GUARD CLOSED
Observer's Audio Selector.....NORM
Aisle Stand Panel Light CtrlMID POSITION
Aisle Stand Flood Light CtrlMID POSITION
Seat.....ADJUST
Rudder Pedals.....ADJUST
Hud Combiner.....DOWN
Seat Belt & Shoulder HarnessADJUST

Pre-Flight Procedure Left Seat

EFIS Control Panel.....SET
Flight Instruments.....CHECK
Air Data / Attitude Source Selector.....,.....AUTO
PFD/MFD Selector.....AUTO
Forward Panel Brightness Control.....MID POS
Inboard and Outboard Display Selectors.....MID POS
Electronic Flight Bag.....SET
Oxygen.....TEST and SET
Left Tuning and Control Pnl.....SET
Captain's Audio Control PnlAS NEEDED
Seat.....ADJUST
Rudder Pedals.....ADJUST
Hud Combiner.....DOWN
Seat Belt & Shoulder HarnessADJUST